




! WARNING !

ALWAYS unplug your sink from the wall outlet before performing any maintenance or attempt any troubleshooting unless electricity is required. Always follow your Owner's Manual.

Step 1




! WARNING !

ALWAYS Unplug the sink from the wall outlet and turn it off before performing any of these steps.

Step 2

Locate the plastic cord connectors at the bottom of the pump.



Step 3
Push both plastic cord connectors in until you hear a distinct snap.

